TB-1409291A Upgrading Orion Firmware

Cameron Grant, M.Sc. P. Eng., Sigma Eight Inc. September 29, 2014

The following is the procedure for upgrading the firmware of your Orion Receiver:

- 1. Copy new .img file into the PiscesTool Directory (c:\program files\OrionTool or c:\SEI\OrionTool).
- 2. Put a blank MMC card in your computer.
- 3. Open up OrionTool.
- 4. Make sure the proper MMC drive is selected under Options / Set Options.
- 5. Click "OK".
- 6. Select "Upload Firmware to MMC".
- 7. Find the new .img file and select it.
- 8. Click "OK" and the file will be uploaded.
- 9. Take the MMC card out of your computer.
- 10. Pause your Orion and put the card with the Firmware into slot A.
- 11. Unpause your receiver.
- 12. When the lights finish flashing and go out completely and remain out, the new firmware has been loaded.
- 13. Pull out the MMC card.
- 14. Cycle the power on the Orion to restart it.
- 15. You are now running the new firmware on Orion.
- 16. You can verify the version by clicking on "Config Orion" and clicking the "Factory" tab.